

TEIJO® 2005

PRODUCT DESCRIPTION

TEIJO 2005 is liquid, water based cleaner, suitable for cleaning of all metals.

PROPERTIES

TEIJO 2005 efficiently removes remaining parts of machining oil, pigment dirt and other greasy contamination.

APPLICATION

TEIJO 2005 is used for cleaning of all metals and composition metals in washing applications, but can also be used at dip cleaning or at electrolytic cleaning.

Please find below recommendations of concentrate and temperature for different applications. More exact recommendation can be given first when application, quantity and type of contamination are known.



UN1814

Potassium hydroxide solution

Corrosive liquid

IMO class 8

UN 1814

Packing group III

	Conc. (%)	Temp. (°C)
Washing	2-5	50-80
Dip cleaning	2-5	50-80

Technical data

Consistence		Liquid
Density at 20°C, kg/m³		1290
pH, 3% solution	11,6	

First aid measures

- General information: Immediately remove any clothing soiled by the product.
- After inhalation:
Supply fresh air; consult doctor in case of complaints.
In case of unconsciousness place patient stably in side position for transportation.

· After skin contact:

Immediately wash with water and soap and rinse thoroughly.
Seek medical treatment.

· After eye contact:

Rinse opened eye for several minutes under running water.
Protect unharmed eye.
Call a doctor immediately.

· After swallowing:

Rinse out mouth and then drink plenty of water.
Do not induce vomiting; call for medical help immediately.

· Information for doctor:

Treat according to symptoms (decontamination, vital functions), no known specific antidote.